



been reached, you can turn off your pump and disconnect.

## **2. Charging System:**

Depending on 2 way or 4 way manifold use, now check and make sure that you have your service (yellow) hose connected to your refrigerant tank. Turn on your scale from the monitor and then place your tank on the platform after the scale has finished its countdown. At this point open your blue and red valves on the manifold and then open the valve on your refrigerant tank. The charging process will begin at this point and the amount being charged to your system can be viewed on the scale monitor. Depending on outside temp. conditions, you may need the assistance of a heater blanket around your tank to speed up the charging process. Once your desired charge amount is reached, close all valves and then disconnect all hoses, as your charge process is complete.